

[TIAS BLOG LINK](#)

Note: for those who prefer front side/back side tatting the text in italics and red indicates where the worker needs to use the second half of the ds first. Please ignore if you don't want the added 'hassle'!!!!

Abbreviations

R	ring	Ch	chain
p or -	picot	Cl	Close ring
RW	Reverse work	vsp	Very small picot
+	join		

Today's Piece

R5: 3 + (vsp R4) 3 - 3 vsp 3 Cl RW

Ch: 3 - 3 RW

R6: 3 + (vsp R5) 4 vsp 5 Cl RW

Ch: 6 - 6 RW

R7: 5 + (vsp R6) 4 vsp 3 Cl RW

Ch: 6 RW

R8: 3 + (vsp R7) 3 - 3 vsp 3 Cl RW

Ch: 6 RW

R9: 3 + (vsp R8) 4 vsp 5 Cl RW

Ch: 6 - 6 RW

